

OPERATING INSTRUCTIONS
FOR
MODEL SV-1
INTERMEDIATE PERIOD
VERTICAL SEISMOMETER

November 1978
Revised, July 1987

KINEMATICS, INC.
222 Vista Avenue
Pasadena, California 91107
(818) 795-2220

1.0 GENERAL DESCRIPTION

The SV-1 Vertical Seismometer is an intermediate period, portable, field seismometer. It is contained in a rugged, weather-tight housing which measures $13\frac{1}{2}$ x 6 x 7 inches high and weighs 21 pounds. The housing includes a window for viewing the position of the mass. Also, the window is removable for access to the mass centering knob, the mass caging device, and the period adjustment screw, without removing the entire cover.

The basic elements of the SV-1 Seismometer are identified in Figure 1. The mass and coils are suspended at one end of a horizontal boom. The other end of the boom is supported by a flexural pivot. The suspension spring balances the weight of the mass against gravity. The period adjusting screw varies the attitude of the suspension spring relative to the boom and pivot, and thus determines the natural period of the seismometer. The coils are carried by the circuit board attached to the mass, and as the instrument base moves with ground motion, the coils are displaced relative to the magnets and an output is generated. The coils also contain a separate winding for application of a calibration pulse.

1.1 Typical Characteristics

| | |
|---------------------------------|------------------------|
| Natural period | 5 seconds |
| Coil resistance | 3800 ohms |
| Critical damping resistance | 22,000 ohms |
| Generator constant | 270 volts/meter/second |
| Maximum ground movement | ± 2 mm |
| Calibration coil force constant | .12 newton/ampere |

2.0 SET-UP

2.1 Installation

The SV-1 Seismometer should be installed on a hard base, such as a concrete floor. Any material which may tend to flow under pressure will not make an adequate base. For example, the sharp points on the three feet tend to slowly sink into asphalt tile floors, and as with any extended period seismometer, may result in drift of the mass position. When emplacement on soft materials cannot be avoided it is recommended that the feet be placed on pieces of hard material of relatively large area, such as tile or brick, or special foot pads available from Kinometrics.

2.2 Electrical Connections

Electrical connections are shown in Figure 2. A mating connector (PT06E-8-4P(SR)) is supplied with the seismometer. All connections to the output coil should be made with a high-quality, plastic-insulated, shielded, twisted-pair cable. The shield should be grounded at one end only, preferably at the amplifier (or galvanometer) end.





FIGURE 1



Coil Polarity

- Signal Coil:** Mass movement down (ground motion up) produces positive voltage at A (B common).
- Calibration Coil:** Positive voltage at C (D common) produces mass movement down.
- Note:** Magnets are poled so that coils are connected in a hum-bucking configuration.

Figure 2
Electrical Connections

2.3 Uncaging the Mass

To free the mass, rotate the slotted mass caging shaft clockwise. There are detents at both the fully caged and uncaged positions. When the mass is uncaged, the caging pin still extends partially into the hole in the mass, providing a limit stop for the mass travel.

2.4 Mass Centering

Before centering the mass, it is necessary to level the seismometer base. There are two ways to determine that the base is level. The recommended method is to use the small bubble level attached to the top of the cover. This method does not require removal of the cover which is especially important for field installations since dust or dirt inside the seismometer will interfere with proper operation. Also, it will provide an adequate measure of level for nearly all applications. An alternative method to determine that the base is level is to remove the cover and place a precision level directly on the base. This should be done only in a clean environment where no dust or dirt particles will get inside the seismometer. To level the seismometer base, first adjust the two leveling feet at the end opposite from the connector until the base is level in the transverse direction. Then adjust the single leveling foot at the connector end to level the base in the lengthwise direction.

To center the mass, remove the window from the cover. Turn the centering knob to bring the mass to its centered position. A mirror is mounted in the seismometer for ease in viewing the mass position indicator through the opening in the top of the cover. When the line on the mass is aligned with the black lines on the indicator bracket, the mass is centered, see Figure 3. The red lines on the indicator bracket show the proper operating range for the mass. The seismometer characteristics will be within the specifications when the mass is positioned between the red lines. When the mass is positioned outside the red lines, the seismometer will usually continue to function, but the characteristics (natural period, damping, generator constant) may deviate from specified values.




Figure 3
Mass Centering

3.0 CHECKOUT

All adjustments of the seismometer are made at the factory. A calibration data sheet is supplied with each unit. However, if it is desired to check these values the following procedure is recommended.

3.1 Natural Period

If the seismometer is connected to a recorder, the period can be measured by pulsing the calibration coil (see Figure 4) and recording the oscillations of the mass. The time-per-unit cycle is the natural period, T_n . The recorder should have a very high input impedance, 1 megohm or higher, or it will contribute significant damping to the seismometer.

3.2 Damping

The damping is adjustable by changing the resistance across the output coil. The required resistance for any desired damping may be computed from

$$R_x = \left(\frac{CDR}{h_t - h_m} \right) - R_c$$

where R_x = Resistance of external circuit, ohms

CDR = Critical damping resistance, ohms

h_t = Total damping with external resistance R_x


h_m = Damping with $R_x = \text{infinity}$

R_c = Coil resistance, ohms

The values of CDR, h_m , R_c and R_x for $h_t = 0.7$ critical damping are given on the calibration data sheet. To check these values, the response to a step function must be recorded. The recommended test set up is shown in Figure 4. First, run a record without an external resistor ($R_x = \text{infinity}$). Measure the overshoot ratio, x_2/x_1 and convert to damping by means of Table 1. The value obtained with no external resistance is the internal damping, h_m .

Next, use $R_x = 100K$ ohms and run another record. From this overshoot ratio, determine the damping for $R_x = 100K$ ohms. The value of CDR may now be computed from

$$CDR = (h_t - h_m) \times (R_c + R_x)$$




NOTE: To measure natural period, use $R_x = \text{infinity}$.

If the recorder does not have a very high input impedance, the effective value of R_x will be the variable resistance shunted by the input impedance.

S1 should be a normally-open pushbutton switch.

OPERATION: Close switch S1 and allow the recorder trace (i.e., seismometer mass) to settle down. Open S1 and record the oscillations. The record should appear as shown:



Typical Record
with $R_x = \text{infinity}$

Typical Record
with $R_x = 100\text{K ohms}$

$$\text{Overshoot ratio} = \frac{X_2}{X_1} = \frac{X_3}{X_2}$$

Figure 4

Natural Period and Damping Tests

3.3 Generator Constant

The generator constant or output of the seismometer can be computed from

$$G = \sqrt{\frac{17.1 \cdot (\text{CDR})}{T_n}}$$

where G = The output in volts/meter/second

T_n = Natural period of the seismometer in seconds

CDR = Critical damping resistance in ohms

and (17.1) is a constant derived from physical characteristics of the seismometer including mass, moment of inertia, spring constant, and geometric dimensions.

4.0 OPERATION

4.1 Normal Operation

Adjust the external resistance across the output coil to give the desired damping. Be sure to include the effect of the amplifier input impedance, or galvanometer coil resistance, as part of the external resistance.

If desired, a calibration run may be made at the beginning of each record. With the mass centered and the proper damping resistance across the output coil, pulse the calibration coil as shown in Figure 4. The resulting record will show the damped response of the system. Depending on the sensitivity of the system, R_{cal} should be selected to give an on-scale trace excursion of convenient amplitude, or so as not to exceed the dynamic range of associated electronics.

CAUTION: In making the calibration record and for actual operation, it is essential that switch S1 be open so that no resistance is connected across the calibration coil.

4.2 Loaded Generator Constant

The output of the seismometer with the damping resistance in the circuit (the loaded generator constant, G_L) represents the unattenuated seismometer output received at the input of the amplifier or galvanometer. It is computed from

$$G_L = G \cdot \frac{R_x}{R_x + R_c}$$

where G = Open circuit generator constant in volts/meter/
second

R_x = External damping resistance, ohms

R_c = Coil resistance, ohms

4.3 Caging the Mass

If the seismometer is to be moved to a new location, the mass must be caged before transportation. To do this, turn the caging screw counterclockwise until the mass is caged.

TABLE 1

OVERSHOOT RATIO VS. DAMPING

| OVERSHOOT RATIO (E) | DAMPING (h) | OVERSHOOT RATIO (E) | DAMPING (h) |
|------------------------|----------------|------------------------|----------------|
| 0.01 | 0.82609 | 0.51 | 0.20957 |
| 0.02 | 0.77970 | 0.52 | 0.20378 |
| 0.03 | 0.74480 | 0.53 | 0.19808 |
| 0.04 | 0.71565 | 0.54 | 0.19247 |
| 0.05 | 0.69011 | 0.55 | 0.18694 |
| 0.06 | 0.66713 | 0.56 | 0.18150 |
| 0.07 | 0.64608 | 0.57 | 0.17613 |
| 0.08 | 0.62658 | 0.58 | 0.17084 |
| 0.09 | 0.60833 | 0.59 | 0.16563 |
| 0.10 | 0.59116 | 0.60 | 0.16049 |
| 0.11 | 0.57489 | 0.61 | 0.15543 |
| 0.12 | 0.55942 | 0.62 | 0.15043 |
| 0.13 | 0.54465 | 0.63 | 0.14551 |
| 0.14 | 0.53051 | 0.64 | 0.14065 |
| 0.15 | 0.51693 | 0.65 | 0.13585 |
| 0.16 | 0.50387 | 0.66 | 0.13112 |
| 0.17 | 0.49127 | 0.67 | 0.12645 |
| 0.18 | 0.47911 | 0.68 | 0.12185 |
| 0.19 | 0.46735 | 0.69 | 0.11730 |
| 0.20 | 0.45595 | 0.70 | 0.11281 |
| 0.21 | 0.44490 | 0.71 | 0.10838 |
| 0.22 | 0.43417 | 0.72 | 0.10400 |
| 0.23 | 0.42374 | 0.73 | 0.09968 |
| 0.24 | 0.41359 | 0.74 | 0.09541 |
| 0.25 | 0.40371 | 0.75 | 0.09119 |
| 0.26 | 0.39409 | 0.76 | 0.08702 |
| 0.27 | 0.38470 | 0.77 | 0.08291 |
| 0.28 | 0.37554 | 0.78 | 0.07884 |
| 0.29 | 0.36660 | 0.79 | 0.07482 |
| 0.30 | 0.35786 | 0.80 | 0.07085 |
| 0.31 | 0.34931 | 0.81 | 0.06692 |
| 0.32 | 0.34096 | 0.82 | 0.06304 |
| 0.33 | 0.33278 | 0.83 | 0.05921 |
| 0.34 | 0.32478 | 0.84 | 0.05541 |
| 0.35 | 0.31694 | 0.85 | 0.05166 |
| 0.36 | 0.30926 | 0.86 | 0.04795 |
| 0.37 | 0.30173 | 0.87 | 0.04429 |
| 0.38 | 0.29435 | 0.88 | 0.04066 |
| 0.39 | 0.28710 | 0.89 | 0.03707 |
| 0.40 | 0.28000 | 0.90 | 0.03352 |
| 0.41 | 0.27302 | 0.91 | 0.03001 |
| 0.42 | 0.26617 | 0.92 | 0.02653 |
| 0.43 | 0.25945 | 0.93 | 0.02309 |
| 0.44 | 0.25284 | 0.94 | 0.01969 |
| 0.45 | 0.24634 | 0.95 | 0.01633 |
| 0.46 | 0.23996 | 0.96 | 0.01299 |
| 0.47 | 0.23368 | 0.97 | 0.00970 |
| 0.48 | 0.22750 | 0.98 | 0.00643 |
| 0.49 | 0.22143 | 0.99 | 0.00320 |
| 0.50 | 0.21545 | 1.00 | 0.00000 |